



















ASSEMBLY INSTRUCTION model HARMONY C

1. -2 Pcs. 	2. -2 Pcs. 	3. -3 Pcs. 	4. -1 Pc. 	5. -2 Pcs. 	6. -2 Pcs. 	7. -1 Pc. 
8. -2 Pcs. 	9. -1 Pc. 					

A. -10 Pcs. 	B. -4 Pcs. 	C. -1 Pc. 	D. -10 Pcs. 	E. -10 Pcs. 	F. -12 Pcs. 
G. -4 Pcs. 	H. -4 Pcs. 	I. -8 Pcs. 	J. -2 Pcs. 